

INSTALLATION PROCESS:  
**FK003D767R Rear Brake Line Kit**  
2011-2013 HONDA CB 1000R

Torque specifications  
Stainless steel 15-17 ft. lbs  
Aluminum 12-15 ft. lbs



**Step 1:**

Identify the key components that complete our brake line kit:

You should have one (1) line, two (2) single banjo bolts and two (2) c-clips. We have also included a total of six (6) washers; four (4) will be used, and two (2) will be spares. We strongly suggest having a professional mechanic install your brake lines, all other installs may void your warranty.

**Step 2:**

To ensure there is no paint damage from the brake fluid, completely cover the rear end of the bike. Installing brake lines can be a messy process, and brake fluid *WILL* spill!

**Step 3:**

After bleeding and drying out the OEM brake system, uninstall your rear stock hose. Take note of how the stock system was routed in case you need to re-install the hose.

**Step 4:**

Identify which end of your new Galfer brake line to install at the rear master cylinder. Install this end to the master cylinder using a single banjo bolt and two (2) washers, the sequence will be as follows; master cylinder, washer, banjo fitting, washer, single banjo bolt (**see picture A.**)

**Step 5:**

**Following the OEM routing:** Route the line behind the rear shock and over to the swing arm, use one of the Galfer provided c-clips and OEM bolt to retain the line to the swing arm. Continue routing the line down the swing arm using the stock mounting points along the way (**see pictures B & C.**) Route the line down to the inner swing arm, use the other Galfer provided c-clip and OEM bolt to retain the line, continue down the inner swing arm and towards the rear caliper. Install this end to the caliper using a single banjo bolt and two (2) washers, the sequence will be as follows; caliper, washer, banjo fitting, washer, single banjo bolt (**see pictures D, E & F.**)

**Step 6:**

Before you begin the next step, please check the clearance of your new line. When the rear end is fully extended or compressed, make sure the line is not binding with anything. Be sure to triple check that the line is traveling correctly and is clear from any obstructions.

**Step 7:**

Bleed your brake system according to the owner's manual. Add Galfer DOT-4 brake fluid to the system and build appropriate pressure.

**Step 8:**

Once you have bled the system, please check the brake fluid level in your master cylinder. Top off your brake fluid according to your manual and close the brake fluid reservoir. To ensure there are no leaks or other issues, use a jug or something similar to apply pressure to your brake pedal for at least 2 hours. If the line is not leaking and all else looks good, (bolts are tight and torqued down to specification, washers are in place, and the line is clear from obstruction) you are now ready to ride with the new brake system.

Please be aware that the overall braking feel has been changed dramatically. We suggest taking it easy while you get used to the new brake lever pressure and feel. We recommend checking your brake system periodically; be sure to check that your bolts are tight and *VERY* carefully check your line for any leaks or damage. If there are any signs of damage or stress to the lines, the complete brake line kit will need to be replaced. Remember, our brake lines have a **LIFETIME WARRANTY!** If you have any problems or questions, do not hesitate to call our tech department - **(800) 685-6633.**



**A. Rear Master Cylinder**



**B. Galfer line running behind shock and through c-clip at swing arm**



**C. Galfer line through OEM line holders along swing arm**



**D. Galfer line running down to c-clip at inner swing arm**



**E. Close up of Galfer line and c-clip at inner swing arm**



**F. Galfer line at Rear Caliper**

**GALFER USA**  
**310 IRVING DRIVE**  
**OXNARD, CA 93030**  
**PH (805) 988-2900 . FAX (805) 988-2948**  
**WWW.GALFERUSA.COM**

