

INSTALLATION PROCESS:

FK003D687-3 Front Brake Line Kit

1984-1985 Yamaha FJ1100 Non ABS

1986-1987 Yamaha FJ1200 Non ABS

Torque specifications
Stainless steel 15-17 ft. lbs
Aluminum 12-15 ft. lbs



Step 1:

Identify the key components that complete our brake line kit:

You should have three (3) brake lines, four (4) single banjo bolts and one (1) double banjo bolt. We have also included a total of thirteen (13) washers; eleven (11) will be used, and two (2) will be spares. We strongly suggest having a professional mechanic install your brake lines, all other installs may void your warranty.

Step 2:

To ensure there is no paint damage from the brake fluid, completely cover the front end of the bike. Installing brake lines can be a messy process, and brake fluid *WILL* spill!

Step 3:

After bleeding and drying out the OEM brake system, uninstall your front stock hoses. Take note of how the stock system was routed in case you need to re-install the hoses.

Step 4:

Familiarize yourself with the new Galfer brake lines; notice there is a "right" and "left" line, this is as if you are sitting on the bike, as well as a "top" or master cylinder line. Install the top line to the front master cylinder using a single banjo bolt and two (2) washers, the sequence will be as follows; master cylinder, washer, banjo fitting, washer, single banjo bolt (**see picture A.**)

Step 5:

Route the other end of the "top" line down from the master cylinder to the top of the stock distribution piece on the lower triple tree, install this end of the line using the same sequence as the master cylinder. Install the remaining two lines to the bottom of the distribution piece starting with the left line first, using a double banjo bolt and three (3) washers. The sequence will be as follows; distribution piece, washer, left line banjo fitting, washer, right line banjo fitting, washer, double banjo bolt. Continue routing the lines down behind the forks and to the appropriate calipers. Install each line to the appropriate caliper using a single banjo bolt and two (2) washers, the sequence will be as follows; caliper, washer, banjo fitting, washer, single banjo bolt (**see pictures B, C & D.**)

Step 6:

Before you begin the next step, please check the clearance of your new lines. When the front end is fully extended or compressed, make sure the lines do not bind with anything. Be sure to triple check that the lines are traveling correctly and are clear from any obstructions.

Step 7:

Bleed your brake system according to the owner's manual. Add Galfer DOT-4 brake fluid to the system and build appropriate pressure.

Step 8:

Once you have bled the system, please check the brake fluid level in your master cylinder. Top off your brake fluid according to your manual and close the brake fluid reservoir. To ensure there are no leaks or other issues, zip-tie the brake lever to the throttle for at least 2 hours. If the line(s) are not leaking and all else looks good, (bolts are tight and torqued down to specification, washers are in place, and lines are clear from obstruction) you are now ready to ride with the new brake system.

Please be aware that the overall braking feel has been changed dramatically. We suggest taking it easy while you get used to the new brake lever pressure and feel. We recommend checking your brake system periodically; be sure to check that your bolts are tight and *VERY* carefully check your lines for any leaks or damage. If there are any signs of damage or stress to the lines, the complete brake line kit will need to be replaced. Remember, our brake lines have a **LIFETIME WARRANTY!** If you have any problems or questions, do not hesitate to call our tech department - **(800) 685-6633**.



A. Top line at Front Master Cylinder



B. Galfer lines at the stock Distribution Piece



C. Notice the lines routing behind fork



D. Right Caliper (Left Caliper will look the same)

GALFER USA
310 IRVING DRIVE
OXNARD, CA 93030
PH (805) 988-2900 . FAX (805) 988-2948
WWW.GALFERUSA.COM

