

INSTALLATION PROCESS:  
**FK003D348SB Front Superbike Brake Line Kit**  
2003-2004 Honda CBR 600RR  
**RACE USE ONLY**



**Step 1:**

Identify the key components that complete our brake line kit:

You should have two (2) lines, one (1) double banjo bolt, two (2) male adapters, and one (1) zip tie. We have also included a total of seven (7) washers; five (5) will be used, and two (2) will be spares. We strongly suggest having a professional mechanic install your brake lines, all other installs will **VOID** your warranty. ***Be sure to inspect your brake lines before and after every race.***

**Step 2:**

To ensure there is no paint damage from the brake fluid, completely cover the front end of the bike. Installing brake lines can be a messy process, and brake fluid **WILL** spill!

**Step 3:**

After bleeding and drying out the OEM brake system, uninstall your front stock hoses. Take note of how the stock system was routed in case you need to re-install the hoses.

**Step 4:**

Install the Galfer male adapters onto each caliper using one (1) washer. Torque down to 12 – 13 ft pounds.

**Step 5:**

Familiarize yourself with the new Galfer brake lines; notice there is a “right” and a “left” line, ***this is as if you are sitting on the bike.*** Install the banjo fittings to the master cylinder using the double banjo bolt and three (3) washers, the sequence will be as follows; master cylinder, washer, right line banjo fitting, washer, left line banjo fitting, washer, double banjo bolt. Torque down to 12 – 17 ft pounds (**see picture A.**)

**Step 6:**

Route the lines down to the lower triple tree. Use the Galfer provided zip tie and tie the lines together. Continue to route the lines behind the forks and down to their appropriate calipers (**see picture B.**)

**Step 7:**

Install each line to the already-installed male adapters at the calipers, be sure to position the fitting **35°** away from the bike and torque down to 6 ½ ft pounds (**see pictures C & D.**)

**Step 8:**

Before you begin the next step, please check the clearance of your new lines. When the front end is fully extended or compressed, make sure the lines do not bind with anything. Be sure to triple check that the lines are traveling correctly and are clear from any obstructions.

**Step 9:**

Bleed your brake system according to the owner’s manual. Add Galfer DOT-4 brake fluid to the system and build appropriate pressure.


**Step 10:**

Once you have bled the system, please check the brake fluid level in your master cylinder. Top off your brake fluid according to your manual and close the brake fluid reservoir. To ensure there are no leaks or other issues, zip-tie the brake lever to the throttle for at least 2 hours. If the lines are not leaking and all else looks good, (bolts are tight and torqued down to specification, washers are in place, and lines are clear from obstruction) you are now ready to ride with the new brake system.


Please be aware that the overall braking feel has been changed dramatically. We suggest taking it easy while you get used to the new brake lever pressure and feel. **We recommend checking your brake system periodically; be sure to check that your bolts are tight and VERY carefully check your lines for any leaks or damage.** If there are any signs of damage or stress to the lines, the complete brake line kit will need to be replaced. Remember, our brake lines have a **LIFETIME WARRANTY!** If you have any problems or questions, do not hesitate to call our tech department - **(800) 685-6633.**



**A. Master Cylinder**



**B. Lines Tied at Lower Triple Tree**



**C. Left Caliper**



**D. Right Caliper, Notice Line turned slightly away from bike**

**GALFER USA**  
310 IRVING DRIVE  
OXNARD, CA 93030  
PH (805) 988-2900 . FAX (800) 685-6633  
[WWW.GALFERUSA.COM](http://WWW.GALFERUSA.COM)

